

ASSEMBLY INSTRUCTION – 1898 TOTE JACK

CAUTION: Do not discard the empty shipping carton until assembly is complete; this will avoid unnecessary loss of parts.

Tap one Axle Cap securely onto one end of the Axle, then slip a Wheel onto the Axle with the recessed face next to the Axle Cap. Slide the un-capped end of the Axle through the Axle Cover and place the other Wheel on the Axle. Make sure that each Wheel has the projecting side of the hub toward the center, and then attach the other Axle Cap.

In case of parts shortages or defects, describe missing or defective part by name as used in these instructions, and report to the manufacturer:

WARREN STEEL SPECIALTIES CORPORATION
P.O. BOX 1391 Warren, Ohio 44482
(330) 399-8360